


ASSEMBLY-DD2200-FUSELAGE

FIGURE N°	PART NUMBER	NOMENCLATURE / DESCRIPTION	QUANTITY PER SET	MEASURE UNIT
1	FD52	Canopy	1	PC
2	FC03	Canopy frame air inlet port	2	PC
3	FE07	Bolt	2	PC
4	F	Fuselage cabin	2	PC
5	FD07	Dashboard cover	1	PC
6	FD03	Fuselage wing mount cover	1	PC
7	CG15	Main control stick	2	PC
8	FD48-2	Canopy glass	2	PC
9	FA22	Foot pedal fixed plate	2	PC
10	FCL03	Engine cowling left air inlet port	2	PC
11	FD49	Fuel filler maintenance hole cover	1	PC
12	DIN-F-TL-01	Floats lug	2	PC
13	F	Fuselage shell	1	PC
14	FD09	Engine hood	1	PC
15	FDL51	Engine compartment left air inlet hood	2	PC
16	TL	Left float	1	PC
17	DIN-F-01	Exhaust pipe	1	PC
18	TR	right float	1	PC
19	FGL03	Canopy left arm	1	PC
20	DIN-F-02	Vertical tail	1	PC
21	FA48	Sealing of vertical stabilizer cowling	1	PC
22	DIN-F-03	Sealing Rubber Strip	1	PC
23	DIN-F-04	Lock nut M12	1	PC
24	DIN-F-05	Gasket	1	PC
25	DIN-F-06	Lug M12	1	PC
26	DIN-F-07	Gasket	4	PC
27	DIN-F-08	Lock nut M5	4	PC
28	DIN-F-09	Bolt M5	4	PC
29	DIN-F-10	Bolt M6	2	PC
30	FGR03	Canopy right arm	2	PC
31	FF46	Canopy arm base	2	PC
32	DIN-F-11	Lock nut M6	2	PC
33	DIN-F-12	Gasket	2	PC
34	FE10	Canopy arm gasket	4	PC
35	FE11	Canopy arm inner lining shaft	2	PC
36	DIN-F-13	Water grain pipe	1	PC
37	FE16	Pump drain outlet	1	PC
38	DIN-F-14	Rivet nut	32	PC
39	DIN-F-15	Rubber washer	32	PC
40	DIN-F-16	Stainless steel washer	32	PC
41	DIN-F-17	Button head screw	32	PC
42	FF01	Fuselage base bearing base	4	PC
43	DIN-F-18	Shaft	4	PC
44	DIN-F-19	Clamp spring	4	PC
45	FD08	Main maintenance hole cover	4	PC

ASSEMBLY-DD2200-FUSELAGE



ALPHA NUMERIC PARTS LIST

PART NUMBER	ASSEMBLY	PAGE N°	FIGURE N°
FD52	ASSEMBLY-DD2200	1	1
FC03	ASSEMBLY-DD2200	1	2
FE07	ASSEMBLY-DD2200	1	3
F	ASSEMBLY-DD2200	1	4
FD07	ASSEMBLY-DD2200	1	5
FD03	ASSEMBLY-DD2200	1	6
CG15	ASSEMBLY-DD2200	1	7
FD48-2	ASSEMBLY-DD2200	1	8
FA22	ASSEMBLY-DD2200	1	9
FCL/R03	ASSEMBLY-DD2200	1	10
FD49	ASSEMBLY-DD2200	1	11
DIN-F-TL-01	ASSEMBLY-DD2200	1	12
F	ASSEMBLY-DD2200	1	13
FD09	ASSEMBLY-DD2200	1	14
FDL/R51	ASSEMBLY-DD2200	1	15
TL	ASSEMBLY-DD2200	1	16
DIN-F-01	ASSEMBLY-DD2200	1	17
TR	ASSEMBLY-DD2200	1	18
FGL03	ASSEMBLY-DD2200	1	19
DIN-F-02	ASSEMBLY-DD2200	1	20
FA48	ASSEMBLY-DD2200	1	21
DIN-F-03	ASSEMBLY-DD2200	1	22
DIN-F-04	ASSEMBLY-DD2200	1	23
DIN-F-05	ASSEMBLY-DD2200	1	24
DIN-F-06	ASSEMBLY-DD2200	1	25
DIN-F-07	ASSEMBLY-DD2200	1	26
DIN-F-08	ASSEMBLY-DD2200	1	27
DIN-F-09	ASSEMBLY-DD2200	1	28
DIN-F-10	ASSEMBLY-DD2200	1	29
FGR03	ASSEMBLY-DD2200	1	30
FF46	ASSEMBLY-DD2200	1	31
DIN-F-11	ASSEMBLY-DD2200	1	32
DIN-F-12	ASSEMBLY-DD2200	1	33
FE10	ASSEMBLY-DD2200	1	34
FE11	ASSEMBLY-DD2200	1	35
DIN-F-13	ASSEMBLY-DD2200	1	36
FE16	ASSEMBLY-DD2200	1	37
DIN-F-14	ASSEMBLY-DD2200	1	38
DIN-F-15	ASSEMBLY-DD2200	1	39
DIN-F-16	ASSEMBLY-DD2200	1	40
DIN-F-17	ASSEMBLY-DD2200	1	41
FF01	ASSEMBLY-DD2200	1	42
DIN-F-18	ASSEMBLY-DD2200	1	43
DIN-F-19	ASSEMBLY-DD2200	1	44
FD08	ASSEMBLY-DD2200	1	45