


装配体-DD6601-起落架

零件编号	部件号	零件名称	每套数量	计量单位
1	MFR01	14寸主起落架右机轮	1	PC
2	MFR02	主起落架右扁簧	1	PC
3	MFL01	14寸主起落架左机轮	1	PC
4	MFL02	主起落架左扁簧	1	PC
5	MF53	主起轮轴固定垫板	2	PC
6	MJ01	刹车盘	2	PC
7	MF52	轮轴螺母	2	PC
8	NR01	11寸前起机轮	1	PC
9	NF59	前机轮轴	1	PC
10	NF24	前起轮叉	1	PC
11	NG01	前起万向轴	1	PC
12	NF25	转向限位块	1	PC
13	NF45	回中限位轴	1	PC
14	NF19	前起主支撑臂	2	PC
15	NF20	主支撑臂支撑块	1	PC

装配体-DD6601-起落架





零部件索引表

部件号		装配体	页码	零件编号
MFR01		装配体-DD6601	1	1
MFR02		装配体-DD6602	1	2
MFL01		装配体-DD6603	1	3
MFL02		装配体-DD6604	1	4
MF53		装配体-DD6605	1	5
MJ01		装配体-DD6606	1	6
MF52		装配体-DD6607	1	7
NR01		装配体-DD6608	1	8
NF59		装配体-DD6609	1	9
NF24		装配体-DD6610	1	10
NG01		装配体-DD6611	1	11
NF25		装配体-DD6612	1	12
NF45		装配体-DD6613	1	13
NF19		装配体-DD6614	1	14
NF20		装配体-DD6615	1	15